

VM 10

Komponentlista / Component list

Number on draw.	Article Number	Pieces	Benämning	Description
1	10710	1	Chucknyckel	Collet Key
2	10570	1	Spännhylsa	Collet
3	10501	1	Spindelnos	Spindle Nose
4	MC6S 3x25	1	Skruv	Screw
5	10211	1	Avvisarskiva	Protection Ring
6	10210	1	Fläkt	Fan
7	10010	1	Hölje, Fläktkyld, Aluminium	Housing, Fan Cooled, Aluminium
7	10010 P	1	Hölje, Tryckluftkyld, Aluminium	Housing, Air Cooled, Aluminium
7	10010 R	1	Hölje, Fläktkyld, Rostfritt	Housing, Fan Cooled, Stainless Steel
7	10010 RP	1	Hölje, Tryckluftkyld, Rostfritt	Housing, Air Cooled, Stainless Steel
8	10300 Ö1	1	Stator, 50V*	Stator, 50V*
8	10300 N6	1	Stator, 184V	Stator, 184V
9	10414	1	Oljesvamp	Oil Sponge
10	10400	1	Bakre Lagerhållare	Rear Bearing Cage
11	10412	1	Oljebehållare	Oil Fountain
12	10150 EMC	1	Slutstycke, Fläktkyld	End Piece, Fan Cooled
12	10150 P EMC	1	Slutstycke, Tryckluftkyld	End Piece, Air Cooled
12	10150	1	Slutstycke, Fläktkyld*	End Piece, Fan Cooled*
12	10150 P	1	Slutstycke, Tryckluftkyld*	End Piece, Fan Cooled*
13	N 937 27 05	1	Kabelförskruvning	Cable Gland
13	17162	1	Kontakthylsa*	Contact House*
13	17160	1	Kontakt med skruv, 3-polig*	Contact with screw, 3-pole*
14	EMC-Kabel 2		Kabel, 6-polig	Cabel, 6-pole
14	TKK 3x1		Kabel, 3-polig*	Cable, 3-pole*
15	10021	1	Skyddsbricka	Protection Ring
16		1	Främre Kullager	Front Ball Bearing
17	10022	1	Oljebehållarring	Oil Fountain Ring
18	10023	1	Oljesvamp	Oil Sponge
19	10200	1	Rotor	Rotor
20		1	Bakre Kullager	Rear Ball Bearing
21	10411	1	Kullagerlock	Ball Bearing Cap
22	11,3x2,4	1	O-ring	O-ring