

VM 17

Komponentlista / Component list

Number on draw.	Article Number	Pieces	Benämning	Description
1	17710	1	Chucknyckel	Collet Key
2	17570	1	Spännhylsa	Collet
3	17501	1	Spindelnos	Spindle Nose
4	17022	1	Oljebehållare	Oil Fountain Ring
5	17023	1	Oljesvamp	Oil Sponge
6	17021	1	Oljebehållarring	Oil Fountain
7	17210	1	Fläkt	Fan
8	17010	1	Hölje, Fläktkyld, Aluminium	Housing, Fan Cooled, Aluminium
8	17010 P	1	Hölje, Tryckluftkyld, Aluminium	Housing, Air Cooled, Aluminium
8	17010 R	1	Hölje, Fläktkyld, Rostfritt	Housing, Fan Cooled, Stainless Steel
8	17010 RP	1	Hölje, Tryckluftkyld, Rostfritt	Housing, Air Cooled, Stainless Steel
9	17300 Ö1	1	Stator, 38V*	Stator, 38V*
9	17300 S2	1	Stator, 189V	Stator, 189V
9	17300 GM	1	Stator, 240V	Stator, 240V
10	19200	1	Rotor	Rotor
11	17400	1	Bakre Lagerhållare	Rear Bearing Cage
12	17150 EMC	1	Slutstycke, Fläktkyld	End Piece, Fan Cooled
12	17150 P EMC	1	Slutstycke, Tryckluftkyld	End Piece, Air Cooled
12	17150 P-AC	1	Slutstycke, Tryckluftkyld, Vinkelansl.	End Piece, Air Cooled, Ang. Conn.
12	17150	1	Slutstycke, Fläktkyld*	End Piece, Fan Cooled*
12	17150 P	1	Slutstycke, Tryckluftkyld*	End Piece, Fan Cooled*
13	17156	3	Skruv	Screw
14	EMC-Kabel 2		Kabel, 6-polig	Cabel, 6-pole
14	TKK 3x1		Kabel, 3-polig*	Cable, 3-pole*
15	MC6S 4x35	1	Spindelnoskruv	Spindle Nose Screw
16		1	Främre Kullager	Front Ball Bearing
17	17211	1	Avvisarskiva	Protection Ring
18		1	Bakre Kullager	Rear Ball Bearing
19	17411	1	Kullagerlock	Ball Bearing Cap
20	17414	1	Oljesvamp	Oil Sponge
21	15,3x2,4	1	O-ring	O-ring
22	17412	1	Oljebehållare	Oil Fountain
23	N 937 27 05	1	Kabelförskruvning	Cable Gland
23	17162	1	Kontakthylsa*	Contact House*
23	17160	1	Kontakt med skruv, 3-polig*	Contact with screw, 3-pole*
23	17160 EMC IM	1	Kontakt, Hane, 6-polig	Contact, Male, 6-pole